



In this document, we'll review the most commonly used icons, what they do, and when to use them during daily operation.

## SCREEN LAYOUT & VIEWING CONTROLS



The **4-screen split**, **9-screen split**, and **16-screen split** icons allow you to view multiple camera feeds at the same time.

These are useful when monitoring several areas simultaneously, with the layout depending on how many cameras you need to see at once.






If you're working with a PTZ camera, the **Open/Close PTZ Control** icon will open the pan, tilt, and zoom controls. This lets you manually move the camera to focus on specific areas.

The **Favorite** icon allows you to mark specific cameras or views so you can access them more quickly later.



The **Zoom** icon allows you to digitally or optically zoom in or out, depending on the camera.

If the camera supports it, the **Iris Adjustment** icon lets you control exposure and brightness.





The **Live View** icon displays the real-time camera feed, while **Quick Playback** allows you to quickly review recent recorded footage without navigating through full playback menus.


Once footage has been recorded, the **Trim/Save Footage** icon lets you cut and save specific clips for later use or sharing.





For fisheye cameras, the **Fisheye** icon enables specialized viewing modes, such as dewarped or multi-angle views.



## AUDIO & VIDEO CONTROLS





To control audio, use the **Mute** icon to turn off camera sound and the **Unmute** icon to turn it back on, assuming the camera supports audio.



The **Standard Definition (SD)** icon lowers the resolution, which can help save bandwidth or improve performance on slower connections.

The **High Definition (HD)** icon switches the live stream to full resolution for the best image quality.


Recommendation: *For optimal performance, limit HD viewing to 4 cameras at a time.*



# IC VIEW PRO ICON OVERVIEW


In this document, we'll review the most commonly used icons, what they do, and when to use them during daily operation.

## RECORDING & PLAYBACK TOOLS







The **Snapshot** icon captures a still image from the live camera feed and saves it to your device.

For Local Recording, using the **Start Recording** icon allows you to record video directly to your phone or tablet instead of the NVR.




To review footage stored on the device or camera memory, use **Play Memory Videos**.

If you need to stop all active video streams at once, select **Close All Videos**.




## CAMERA FEATURES & ADJUSTMENTS




The **Orientation** icon allows you to flip or rotate the camera image to match how the camera is physically mounted.

For supported models, the **Camera Wiper** icon activates the lens wiper to clear water or debris.

The **Light** icon toggles the camera's built-in light or spotlight on and off.



## SYSTEM ALERTS & SECURITY FEATURES



The **Add** icon is used to add new devices or cameras to the system.

The **Alerts** icon shows notifications such as motion detection, intrusion events, or system alerts.

The **Device Details** icon opens detailed information and settings for the selected device.

If the camera includes an audible deterrent, the **Siren** icon activates the built-in alarm sound.

The **Voice Call (2-Way Talk)** icon enables two-way audio communication, allowing you to speak through the camera and hear responses.

